

Fall Factor

Fall Factor = Fall distance

Lenght of lanyard/Rope

The fall factor is the distance fallen, divided by the length of the lanyard or rope available to absorb that fall. The fall factor ranges from 0 to 2. Independently on a fall being long or short, the lower the fall factor, the safer the fall.





Fall Factor 1



